


Observation Coordination Framework


Calle Rosenquist








Observation Coordination Framework Introduction



- Current Baseline
- Preliminary Design
- Control & Data Flow



Observation Coordination Framework Introduction



OCM

Coordinates data acquisition

DPM

Creates FITS files

GM

- Slow guiding facilities
- > Custom



Terminology

Data Acquisition

The process of acquiring data captured by science detectors or other systems

Primary Data
Typically science detector data

Meta Data

Any supporting data, e.g. device manager status information

Data Product FITS file



Goals

- Focused Responsibility
- Standardise Interfaces
- Avoid SW Customization*

Instead:

- Configuration
- Interface

OCM


- Data Acquisition
- Coordination
- Interfaces with data providers


DPM


- Collect Data
- Create Data Products
- Interfaces with On-Line Archive System (OLAS)





Previous Baseline
















OCM/DPM

Features

- Concurrent Data Acquisitions
- Multiple Detector per Data Product
- Offline or deferred "merging"
- Multiple Data Products per Data Acquisition*
 - > Science + e.g. auxiliary AO data




OCM

Provided Interface

- Controlling DAQ
 - Start/Stop/Abort
- Control Data Product Creation*
- Synchronize to different points




Data Acquisition






OCM





DPM





Questions?